Use And Care Of Your BUNN® EASY POUR® Decanter

PLEASE READ AND FOLLOW THESE SIMPLE STEPS.

Rinse Often With Hot Water.

Empty and Rinse the Decanter When Not in Use.

Clean the Decanter Often Using a Sponge Dish Mop and One of the Products Recommended on the Reverse. Rinse Well With Hot Water Before Use.

Remove Excessive Stains by Soaking Overnight in the Cleaning Solution.

Completely Dishwasher Safe.

Never Use Brushes, Pads, Detergents, or Cleaners That Will Scratch.

Never Use A Rinse Aid.

These Products Are Safe for Your

BUNN®
EASY POUR®
Decanter

Name

Manufacture

Cascade

Procter & Gamble Co. (Cincinnati, OH)

Ajax Dishwashing Liquid

Any Source

Mikro-Chlor Sanitizer

Ecolab

Palmolive Dishwashing Liquid

Any Source

Sunlite

Any Source

Urnex Glass bowl Cleaner

Royal Urn Bag Co. (New York, NY)

10310.0000G 6/92 ©1988 Bunn-O-Matic Corporation