

SPARE PARTS – TOMATO PRO AND ECONO PRO

LETTER	PART NUMBER	DESCRIPTION
A	0661	Pusher Head Casting (Old Style)
B	0662	3/6" and 3/8" Pusher Head Assy
	0663**	1/4" Pusher Head Assy
	379035**	7/32" Pusher Head Assy
C	519	Acorn Nut – Used with old style pusher head only
D	0687	Pusher Head Casting (New Style)
E	356	Wing Nut (New Style)
F	305	Rubber Stop
G	0666L	Guide Rod, Left (Long)
H	0666R	Guide Rod, Right (Short)
I	EC0666	Guide Rod (Econo Pro Only)
J	0664	Bridge Casting
K	0674	Bolt, Blade Block (Old Style) Allen Head 1/4-20 x 1 3/8"
	0660	Bolt, Blade Block (New Style) Hex Head 1/4-20 x 1 3/8"
L	047	Bade Block Pin
M	0658	Rubber Seal
N	0673	Set Screw, Guide Rod
O	0671	Platform (Tomato Pro w/out Safety Guard)
	0670	Platform (Tomato Pro with Safety Guard)
	0686	Platform (Econo Pro with Safety Guard)
P	EC0671	Platform (Econo Pro w/out Safety Guard)
Q	2319	Rubber Feet (Econo Pro)
R	060	Rubber Feet (Old Style)
	303	Rubber Feet, Deep (New Style)
S	0667	Base Casting
T	0676	Screw, Retaining (Bridge Casting to Base)
U	369211	Thumb Screw (Insert from top with Econo Pro Safety Guard)
V	0682	Safety Guard – Tomato Pro (New Style)
	0684	Safety Guard – Econo Pro (New Style)
W	0677	Safety Guard – Old Style (NLA – use 0684)
X	0679	Pivot Post, Safety Guard (Old Style)
Y	0678	Spring, Safety Guard (Old Style)
Z	0680	Positive Stop, Pivot Arm
AA	0688	End Bumper, Positive Stop
BB	0650	Blade, Single – Scalloped
	0651	Blade, Single
	0648	Blade Assy 3/16" (15 blades) - Scalloped
	0653	Blade Assy 3/16" (15 blades)
	0652	Blade Assy 1/4" (11 blades) – Scalloped
	0654	Blade Assy 1/4" (11 blades)
	0647	Blade Assy 3/8" (8 blades) – Scalloped
	0656	Bade Assy 3/8" (8 blades)
CC	379036	Washer
DD	379037	Aluminum Stop

**Note: Old style (two studs) pusher head assembly is no longer available. The new style (one stud) pusher head assembly must be used with the new style pusher head casting (P/N 0687).

EXPLODED VIEW – TOMATO PRO AND ECONO PRO

