


GLOSSARY OF TERMS

Please read the following instructions before operating this machine.




Facing side plate is shown removed for diagram purpose only.



For Parts, Assistance, or Additional Information Call:

Phone: 800-847-0101 • Fax: 419-354-0514
12830 S. Dixie Hwy. • Bowling Green, OH 43402 • daymark.com

LOADING INSTRUCTIONS



* After dialing in different information, discard the first label.

DIALING THE PRICES


Pull the knob out to line up the arrow on the DIAL SHAFT with the appropriate band. Push back when the character is set.



1

ADJUSTING THE PRINT HEADS

Loosen both HEAD ADJUSTMENT SCREWS on the print head. Move the print head either forward or backward to line up the copy on the label. Tighten the screws.



1

CHANGING THE INK ROLLER

Lift the INK ROLLER HOLDER slightly away from the marker and lift up until it is clear of the INK ROLLER. Lay the marker on its side over a waste receptacle to "drop" out the old ink roller.



1

Carefully slide the new INK ROLLER back onto the INK ROLLER SHAFT and slip the INK ROLLER HOLDER back to its original position.



2

DO NOT attempt to re-ink the ink rollers; use enclosed replacement roller. Additional ink rollers and labels may be purchased by calling 800-847-0101.

TROUBLESHOOTING

PROBLEM:

CHECK THE FOLLOWING:

Labels are not advancing	✓ Make sure sprocket is advancing. Clean off the adhesive buildup on the sprocket or print base.
Printing is too light on one side of the label	✓ Make sure the ink roller and ink roller holder is making contact with the heads in a uniform manner.
Numbers not printing clearly	✓ Clean the bands with a soft, dry brush. Lint, mixing with ink, will create a buildup on the bands; or replace ink roller.
Bottom cover will not open	✓ It may be caught on the side plates which may need to be slightly pulled outward.
Printing looks too high/low on labels	✓ Adjust the head forward or backward.
Printing hits between two labels	✓ Reload the labels for correct alignment on the sprocket.
Ink roller will not spring back up	✓ Check the springs to be sure they are operating on the ink roller holder.

1-LINE MARKER (DM3)



OPERATING INSTRUCTIONS

DAYMARK® LIFETIME GUARANTEE

DayMark® will repair and recondition your date coding markers as long as labels and ink rollers are being purchased from DayMark. DayMark's replacement policy requires our customers to send in the marker needing reconditioning first, before a replacement marker is issued.

REPLACEMENT INSTRUCTIONS

1. Call your customer service representative at 800-847-0101 to request a replacement marker.
2. A Return Authorization Number (RA#) will be assigned for your return.
3. Label your box for your DayMark marker return.
4. Upon receipt of the return marker, DayMark will ship a replacement marker to you within 24-48 hours. DayMark markers with "special band layouts" will require a longer lead time.

#2889