

Project: _____

Item #: _____ Quantity: _____

Model #: _____



ST-1220
Warming Tray

Glass Surface Measures 13-3/4" Front to Back
 & 20-3/4" Side to Side



Overall Unit Measures 24" Side to Side,
 Including the Handles

- Power Switch & Temperature Adjustment Knob Located on Operator's Side
- Black Smoke, Tempered, Glass Surface
- Satin, Stainless Steel Body
- 200° Surface Temperature (Lowest Temp = 80°)
- Low Profile Design

[EC] Electric Requirements:

Model	Voltage	Phase	Hertz	Watts	Amps	Plug
ST-1220	110	1	60	230	2.1	NEMA 5-15P (6' Cord)

Notes & Conditions:

To clean your Warming Tray, make sure unit is in the power "Off" position. Unplug the unit from the power source.

Make sure the tray surface is at room temperature. Clean the surface of the tray with a damp cloth. Never immerse the Heated Tray in water. Ensure that water is not allowed to pool or sit on the glass surface.

If the surface glass is cracked or damaged, discontinue use

Never attempt to service any part of your Warming Tray on your own. Contact our Service Department by calling 800-535-8974. Attempting to service your Warming Tray on your own, or through an unauthorized repair facility automatically voids your warranty. For service forms, visit the Spring USA website.

Note:

The glass surface of this tray becomes hot. Surface temperature can reach 200°F. To ensure guests' safety, it is recommended that a Cautionary Statement be rendered. If the surface glass of the unit becomes cracked or damaged in any way, discontinue use immediately.

Conforms to NSF 4 Conforms to UL STD 197 Certified to CSA STD C22.2 No. 109

Due to continuous product improvement, specifications are subject to change without notice

